

OPL- CRWN-032

**Description: Changing rear door handle latch**




Unscrew retaining nut  
and remove latch




New Latch

Old Latch



Replace with new latch

Adjust latch position  
before fully tightening



*Allows for easy  
adjustment of the  
latch, side to side.*